

# Power Supply RS232 & RS485 Command Codes

for SR...**Hi** models


## Table of contents

1. Communication Settings.....	3
2. RJ45 connector Pinout.....	3
3. RS232 connections.....	3
4. RS485 .....	4
5. List of commands.....	5
6. List of parameters and data codes .....	6
6.1 Data Codes .....	7

## 1. Communication Settings

Bits/second: 9600  
 Databits: 8  
 Parity:None  
 Stop bits: 1  
 Flow control: Hardware

An **RJ45** connector is used at the SR...H.. Power supply/Charger




See below for connection pin outs to monitor using a PC.

## 2. RS232 models

Use: RJ45 – DB9 female adaptor with RJ45 to RJ45 (Cat5e) cable **plus** DB9 male to USB cable.

## RS232



RJ45	DB9 (female)
4	5
5	3
6	2

### 3. RS485 models

Use **FTDI** USB to RS485 serial converter (**USB-RS485-WE**) cable to RJ45 connector

<b>RJ45</b>	<b>Cat5e/6e</b>	<b>Signal</b>	<b>FTDI USB-RS485-WE Cable</b>
1	White/Green	Data+ (A)	Orange (5)
2	Green	Data- (B)	Yellow (2)
4	Blue	GND	Black (1)

RJ45 connector at SR...H.. charger/power supply

FTDI cable reference:

[https://www.ftdichip.com/Support/Documents/DataSheets/Cables/DS\\_USB\\_RS485\\_CABLES.pdf](https://www.ftdichip.com/Support/Documents/DataSheets/Cables/DS_USB_RS485_CABLES.pdf)

## 5. List of commands (use CAPITAL letter for alpha commands)

- 1** Start float charge (cc)
- 2** Request configuration data
- 3\*** Set to receive new config data
- 4\*** Set to receive new timing data
- 6** Request time left before next BCT
- 7** Request time left in BCT
- 8** Request time left in EQ
- AR\*** Trigger output 1 for 5 seconds
- AY\*** Enable/disable auto Equalisation charge
- C** Clarify reason of Mains fail alarm
- D** Request state information
- E\*** Start equalisation charge
- F** Request measurement data
- G** Start BCT
- H** Stop BCT
- I** Enable scheduled BCT
- J** Disable scheduled BCT
- K** Request BCT info (BCT enabled or disabled)
- L** Reset temperature log
- M** Request DC high alarm threshold
- TO\*** Adjust BCT length
- TP\*** Adjust CC days
- TQ\*** Adjust CC hours
- TR\*** Adjust CC minutes
- TU\*** Adjust EQ hours
- TW\*** Adjust boost hours
- VP\*** Adjust V present
- VQ\*** Adjust V shutdown
- VR\*** Adjust V batlow
- VU\*** Adjust V disconn
- VW\*** Adjust V equalisation
- VY\*** Adjust V boost
- XPP\*** Set to XPP secure comms.
- Z** Request internal temperature
- ~** Request firmware date
- ?** Request this list of commands
  
- \*** not yet implemented

## 6. List of parameters and data codes


<b>V out</b>	output voltage
<b>V pres</b>	Voltage threshold for battery detection & battery condition test (BCT). If voltage drops to this level during BCT then the test is aborted and BATT SYS OK alarm shows
<b>Vshutd</b>	Output voltage of PSU during battery detection & BCT
<b>V batl</b>	voltage where BATT low alarm activates during mains fail
<b>V disco</b>	Battery disconnect level on low voltage during mains fail
<b>Bccl</b>	Maximum charge current as % of rated PSU rated current
<b>Comms</b>	communications mode of PSU: F = continuous data stream of status, M = responds only to request made by a controller
<b>BatDetect</b>	Battery detection interval time, active only when no battery charge current is detected (the unit may not detect a missing battery for up to this time)
<b>BCT</b>	length of battery condition test
<b>Ret</b>	retest option: N = after a failed BCT further scheduled BCTs are inhibited, Y = after a failed BCT further scheduled BCTs will be allowed
<b>CC</b>	Length of charge cycle in minutes/hours/days. ie. time between battery condition tests

## 6.1 Data Codes

All data is transmitted as direct readable ASCII code.

Typical Screen View:

```
IEL NB5sys.V13 SR100i12T
s/n: 0025 6666 BatDetect:060m
Vpres(1):12.0V Vshutd(2):11.5V
Vbatl(3):11.0V Vdisco(4):10.0V
Bccl(ABC):100% BCT:020m Ret:Y
Comms(MF):F CC:40m 23h 027d
MfiBCT:090m
- CC BM Vout:13.5V Ibat:-00.0A Ipsu:01.4A + 20C
```



### Code A

CC – charge cycle (normal operation)  
MF – mains fail (system on battery power)  
OL – system overloaded, output voltage is below Vpres setting  
BCT – battery condition test is in progress

### Code B

M? – possible mains fail, i.e. no mains detected but brown out timer not expired (30sec)  
m? – same as above, but has failed the previous BCT  
BP – battery present, system OK  
bP – same as above, but has failed the previous BCT  
B? – No battery charge current detected, up to the next scheduled battery detection, uncertainty about the presence of the battery exists.  
b? – same as above, but has failed the previous BCT  
BM - battery is missing, the battery detection routine did not find a battery to be present.  
This will also reset the 'battery condition not good' of a failed BCT.  
BO – battery is in 'OK' state during mains fail  
bO – same as above, but has failed the previous BCT  
BL – battery is in 'LOW' state during mains fail  
bL – same as above, but has failed the previous BCT  
SD – system will shut-down if no mains present and output voltage stays below Vdiscon for 30seconds.

### Displayed values following Code B

Vout = output voltage of PSU  
Ibat = charging current  
Ipsu = total output current  
+20°C = temperature measured by temp. sensor



**Helios Power Solutions  
Australia**

Unit 6, 2-8 South St, Rydalmere  
Meadowbank, Sydney,  
NSW, Australia, 2116

P: +61 2 7200 9200

Sales: [sales@heliosps.com.au](mailto:sales@heliosps.com.au)

Service: [service@heliosps.com.au](mailto:service@heliosps.com.au)

**Helios Power Solutions  
New Zealand**

3 Heremai Street,  
Henderson, Auckland,  
New Zealand, 0612

P: +64 9 835 0700

Sales: [sales@heliosps.co.nz](mailto:sales@heliosps.co.nz)

Service: [service@heliosps.co.nz](mailto:service@heliosps.co.nz)

**Helios Power Solutions  
Middle East & Asia**

168 Robinson Road,  
#12-01 Capital Tower  
Singapore 068912

P: +65 6871 4140

Sales: [sales@heliosps.asia](mailto:sales@heliosps.asia)

Service: [service@heliosps.asia](mailto:service@heliosps.asia)