



### **User Manual**

### **SR100A, D, L, P**

# AC/DC POWER SUPPLY & FLOAT CHARGER FOR LEAD ACID BATTERIES







Model Codes: SR100A .... Standard version

SR100D .... Standard with 2 relay alarm outputs SR100L .... Standard with 3 relay alarm outputs

SR100P.... Standard with 2 alarms and internal output diode





incl. SR100D, SR100P, SR100L

#### 1. INTRODUCTION


The **SR100L** range is designed for use as a very accurate AC to DC power supply, or float charger for lead acid batteries. Note that for float charging the output voltage must be set to approximately 15% above the nominal battery voltage. This is done as the default voltage for the 12V model but must be specified at time of order for all higher voltage models.

#### 2. CONNECTIONS

If used as a float charger always connect the positive output of the power supply to the positive terminal of the battery. The charger may be permanently connected to float charge lead acid batteries but it is essential to periodically check the electrolyte level of flooded cells as there is always some evaporation.

To minimize the volt drop at the output connections use all the terminals provided ie. connect output wires in parallel.

#### **CONNECTION LAYOUTS**



**SR100L** 


#### **ALARM VERSIONS**

Relay contacts shown in **de-energised** state (ie. when there is a fault condition). Alarm relays are **energised** when power supply is operating normally, eg. "Power" alarm relay is energised when input voltage is present.



SR100D

Optional temperature compensation sensor lead




**SR100P..** with output diode. (not avail. for 12 V output).

Note that the diode is in negative line. (tempco lead optional)





incl. SR100D, SR100P, SR100L



SR100L (tempco optional)

3

#### 3.0. LED INDICATION CODES

#### 3.1 -D version

**Power:** On = ac input present

Off = no input or short circuit on output

**DC OK:** Steady on = DC output OK

Slow flash = DC output low or battery low (eg. 11, 22, 33, 44V)

#### 3.2 -L Alarm version

**Power:** On = ac input present

Off = no input or short circuit on output

**DC OK:** Steady on = DC output OK

Slow flash = DC output low or battery low (eg. 11, 22, 33, 44V)

Fast flash = DC high (1.2xVnom for PSU, 2.5V/cell for charger, unless otherwise

specified)

#### 4.0 FG - Frame Ground

Where provided, this terminal provides a connection to the metal case for an earthing-point.



## SR100L

incl. SR100D, SR100P, SR100L



- Industrial quality AC/DC power supply
- Suitable for float charging of lead acid batteries
- Constant current limit
- Precise voltage control
- Efficient modern 'current-mode' topology
- Temperature compensation option
- Suitable for parallel operation
- Optional relay alarm outputs model SR100D,P
- Optional serial communications port, SR100L
- ISO9001 design management system

Ideal as a Standby Float Charger for lead acid batteries

**Dimensions** 

#### 24 Month Warranty

SPECIFICATIONS All specifications are typical at nominal input, full load and at 20°C unless otherwise stated.

ELECTRICAL	
Input	180V - 264VAC 45-65Hz or 200 - 375V DC (standard)
	88V - 132VAC 45-65Hz or 110-180VDC (on request)
Fusing / Protection	Internal AC input fuse

**Isolation** 1KV DC input - output / earth

Efficiency  $\geq 85\%$ 

Inrush current <30A, 1.8ms

Output Power 100W Continuous (0 - 50°C)

Output Voltages 13.8V, 24V, 36V, 48V Other voltages by request.

Voltage adj. range 85 - 115% of Vout

**Temp. Compensation**(option)

Temperature sensor on 1.7m lead with adhesive pad: -4mV / °C / cell ±10%

Over current Protection Constant current limit under overload and

short circuit conditions

**Line Regulation** <0.04% over input range

**Load Regulation** <0.5% open circuit to 100% load

Noise <0.3%

**Transient response** 200mV over/ undershoot,

load step 20-100%, 400us settling time

**Hold-up time** 15 - 20 ms (nom. - max. Vin) without

battery

PHYSICAL	
AC Input connector	IEC320 inlet socket (similar to PCs etc.)
DC Connections	Plug-in style socket & mating screw terminal block: (max. wire 2.5mm² / way)
Enclosure	Zinc plated steel /powder coated lid
Indicators	Green LED for DC Power OK
Weight	0.94 Kg

146.5 W x 62 H x 177 D mm

ENVIRONMENTAL	
Operating temperature	<b>Standard:</b> 0 to 50 °C ambient at full load <b>Option - Low temp:</b> -20 to 50 °C ambient at full load, add suffix <b>-LT</b>
	De-rate linearly >50 °C to 0 load @ 70 °C
Storage temperature	-20 to 85 °C ambient
Humidity  Cooling	0 - 95% relative humidity non-condensing
	Natural convection

STANDARDS	
EMI	to CISPR 22 / EN55022 class A
Safety	to IEC60950 / EN60950 / AS/NZS3260

#### **ACCESSORIES SUPPLIED**

Mounting Feet together with screws

AC power cord Standard 1.5m lead with IEC320 socket / local plug DC connectors with mating screw-terminal plug

# 100 Watt AC/DC Stand Alone Power Supply/Float Charger




incl. SR100D, SR100P, SR100L

STANDARD MODEL TABLE					
	Power Supply		Battery Charger*		
MODELS	Output Volts (factory default)	Output Current (A) (continuous)	Output Volts* (Charging)	Output Current (A) (Charging)	Adjustable range (V)
SR100L12	13.8	7.3	13.8	7.3	11-14
SR100L24	24	4.2	27.6	3.6	22-28
SR100L30	30	3.3	34.5	2.9	27-33
SR100L36	36	2.8	41.4	2.6	34-43
SR100L48	48	2.1	55.2	1.8	45-57

\*Please specify on ordering if unit is to be used for battery charging duty (except for 12V version which is set for 13.8V as standard)

#### **OPTIONAL COMMUNICATION PORT**



#### Available on SR100L... models:

- Three comms. options available: RS485, RS232, Ethernet
- With three relay alarm outputs
- Optional MODBUS protocol converter

#### **CABINET OPTIONS**

19"Rack mount 2U sub rack option: add SR-RM2U

Wall Mount Cabinet May be fitted into a cabinet which includes

two MCBs and I/O terminals Cabinet code: **SEC-SR** 

#### **ELECTRICAL OPTIONS**

Temperature Compensation For accurate battery charging, temperature compensation adjusts voltages in accordance with external temperature probe

Order Code: +TEMPCO

Alarms : SR100D

- Mains fail
- **DC low** (Battery low or PSU low)
  - Charger: set at 1.83V/cell (80% Vout)
  - PSU: set at 83% V out

SR100L

As SR100D plus extra DC alarm and optional comms port

**Alarm Relay Contacts** 

C - NO - NC changeover, rated 30VDC,2A /110VDC,0.3A/125VAC,0.5A

Parallel Redundancy

Use output diode for N+1 redundancy **24V & above:** SR100**P** with alarms and

internal diode

12V: use SR100D12.. and +P15 external

5

diode

#### MODEL CODING SR100L12TXG-485 **485** = RS485 **232** = RS232 LAN = ETHERNET Optional Communications Interface Port (for SR100L... versions only) Input voltage and front Panel standby 230V AC no switch = blank 110V AC no switch = G Output DC connector Phoenix combicon (plug in screw terminal block) = X Temperature Compensation Yes = TNo = blank12, 24, 30, 36, 48 DC output: Nominal voltage A = Standard $\mathbf{D} = \mathbf{A}$ with two alarms Function P = D with internal output diode L = D with extra alarm and optional comms port if required




### N+1 Redundancy


#### CONNECTION FOR PARALLEL REDUNDANCY

Two or more SRxxx series power supplies may be connected in parallel for increased power (with or without diodes). It is essential that the wiring from each unit to the load is kept identical for equal power sharing particularly when diodes are not used.

Two or more SRxxx D series power supplies (standard PSU with alarms), may be connected in parallel for N+1 redundancy using output diodes shown.

Diodes can be fitted inside some power supplies (see models listed below). The SRxxx P series identifies when an internal diode is fitted in the power supply.





**INTERNAL** diodes can be fitted to the following models only (diode is fitted in negative line):

**100W:** SR100P24, SR100P36,

SR100P48

**250W:** SR250P24, SR250P30, SR250P36,

SR250P48, SR250P60

All other models have diodes external to the power supply, eg fitted into a 2U rack as shown in the photo to the right.



2U rack with 2 x SR250D12 power supplies and decoupling diodes on heatsink plus V/I meter



## Installation & Safety

#### Safety

The user is responsible for ensuring that input and output wiring segregation complies with local standards and that in the use of the equipment, access is confined to operators and service personnel. A low resistance earth connection is essential to ensure safety and additionally, satisfactory EMI suppression (see below).

## HAZARDOUS VOLTAGES EXIST WITHIN A POWER SUPPLY ENCLOSURE AND ANY REPAIRS MUST BE CARRIED OUT BY A QUALIFIED SERVICEPERSON.

#### **Electrical Strength Tests**

Components within the power supply responsible for providing the safety barrier between input and output are constructed to provide electrical isolation as required by the relevant standard. However EMI filtering components could be damaged as result of excessively long high voltage tests between input, output and ground. Please contact our technicians for advice regarding electric strength tests.

#### Earth Leakage

Where fitted, EMI suppression circuits cause earth leakage currents which may be to a maximum of 3.5mA.

#### Ventilation

High operating temperature is a major cause of power supply failures, for example, a 10°C rise in the operating temperature of a component will halve its expected life. Therefore always ensure that there is adequate ventilation for the equipment. Batteries in particular suffer shortened lifetimes if subjected to high ambient temperatures.

#### Water / Dust

Every effort must be made in the installation to minimise the risk of ingress of water or dust. Water will almost always cause instant failure. The effects of dust are slower in causing failure of electronic equipment but all electrical equipment should be cleaned free of any dust accumulation at regular intervals.

#### Electromagnetic Interference (EMI)

Switching power supplies and converters inherently generate electrical noise. All wiring should be as short as practicable and segregated from all equipment wiring which is sensitive to EMI. Residual noise can be reduced by looping DC wiring through ferrite cores (sleeves). These are most effective as close to the power supply as possible and as many turns of the wire taken through the core (+ and - in the same direction) as the core will accommodate.

#### **External fuse protection**

Fuses or circuit breakers must be used in all battery circuits to protect against short circuits. External fuses should be used for power supplies/ chargers even though they are usually internally protected.

#### Connection polarity

It is critical to check the polarity carefully when connecting DC devices. Some Innovative Energies models have non-destructive reverse polarity protection but usually a reverse polarity connection will result in a blown fuse or serious damage to the device.

#### Glossary of terms used in our user manuals

**PSU** = power supply unit **BCT** = battery condition test **ECB** = electronic circuit breaker

**ELVD** = electronic low voltage disconnect **RPP** = reverse polarity protection **EMI** = electromagnetic interference

**SNMP** = Simple Network Management **LAN** = local area network **DOD** = depth of discharge

Protocol

MODEL CODE         BASE MODEL         SPECIAL FEATURES           CSR117         SR100A12TX         Operating temp, range -40 to +50°C, temp. compensation disabled below -20°C, conformal coated PCB           SR100L24TX/1         SR100L24TX         Tempco length 4m           Image: Compensation of the property of the proper	CUSTOMISED VERSIONS			
bled below -20°C, conformal coated PCB	MODEL CODE	BASE MODEL	SPECIAL FEATURES	
SR100L24TX/1         SR100L24TX         Tempco length 4m           Image: Control of the	CSR117	SR100A12TX	Operating temp. range -40 to +50°C, temp. compensation disabled below -20°C, conformal coated PCB	
	SR100L24TX/1	SR100L24TX	Tempco length 4m	

#### TERMS OF WARRANTY

Helios Power Solutions warrants this product for 24 months from date of shipment against material and work-manship defects. Liability under this warranty is limited to the replacement or repair of the defective product as long as the product has not been damaged through misapplication, negligence, or unauthorized modification or repair.