

# **ADC5000 SERIES**

AC/DC Switch Mode Power Supplies and Rectifiers for Industrial and Telecom Applications










## 60W, 125W and 250 W

- · Input voltage 230/115 VAC · Output voltages 12, 24, 36 or 48 VDC · Statistical MTBF >3 000 000 hours
- Built in output series diode Temperature compensated battery charging Wide output adjustment range
- · Efficiency 82...90% · Operating temperature −40 °C...+70 °C (see derating) · EMC EN55022B (telecom)







#### POWER SUPPLY MODELS DIN/WALL Type Available Output Output Output Power Mechanical Note Input Voltage Voltage Voltage Current Dimensions \*) <u>xy</u> xy selection codes $(W \times H \times D)$ see below see below (others on request) Adjustment ADC56xy 12 VDC 10.5...15 VDC 51 x 121 x 81 mm xy = 21, 2390...264 VAC 5 A 60 W 230/115 VAC xy = 2312 VDC 9...15 VDC 10 A 120 W ADC50xy 66 x 148 x 113 mm ADC53xy $\underline{xy} = \overline{23}$ 230/115 VAC 12 VDC 9...15 VDC \*\*) \*\*\*) 20/18 A 240 W 75 x 173 x 122 mm \*\*\*) ADC53xyP On request 230/115 VAC 12 VDC 9...15 VDC 20/18 A 240 W 75 x 173 x 122 mm ADC57xy 90...264 VAC 24 VDC 21...29 VDC xy = 21, 232.5 A 60 W 51 x 121 x 81 mm ADC51xy xy = 21, 23230/115 VAC 24 VDC 21...29 VDC 5 A 120 W 66 x 148 x 113 mm 230/115 VAC \*\*) ADC54xy xy = 21, 2324 VDC 21...29 VDC 10 A 240 W 75 x 173 x 122 mm 21...29 VDC ADC54xyP 230/115 VAC On request 24 VDC 10 A 240 W 75 x 173 x 122 mm \*\*\*) ADC59xy 60 W On request 90...264 VAC 36 VDC 33...44 VDC 1.7 A 51 x 121 x 81 mm ADC58xy 90...264 VAC 48 VDC 45...58 VDC 1.25 A 60 W 51 x 121 x 81 mm xy = 2345...58 VDC ADC52xy 230/115 VAC 2.5 A On request 48 VDC 120 W 66 x 148 x 113 mm 230/115 VAC 48 VDC 45...58 VDC 5 A 75 x 173 x 122 mm \*\*) ADC55xy xv = 23240 W On request 75 x 173 x 122 mm ADC55xyP 230/115 VAC 48 VDC 45...58 VDC 5 A 240 W

Device and finger protected power cord must installed place where only skilled person access.

RECTIFIER MODELS DIN/WALL, FLOAT OUTPUT VOLTAGE LEVEL (See Application (A) page 1)								
Type	Available	Input	Output	Output	Output	Power	Mechanical	Note
*) <u>xy</u>	xy selection codes	Voltage	Voltage	Voltage	Current		Dimensions	
see below	(others on request)	-		Adjustment			(W x H x D)	see below
ADC56xy	$\underline{xy} = 83$	90264 VAC	13.7 VDC	10.515 VDC	4.4 A	60 W	51 x 121 x 81 mm	
ADC50xy	$\underline{xy} = 83$	230/115 VAC	13.7 VDC	915 VDC	10 A	137 W	66 x 148 x 113 mm	
ADC53xy	$\underline{xy} = 83$	230/115 VAC	13.7 VDC	915 VDC	20/18 A	274 W	75 x 173 x 122 mm	**) ***)
ADC53xyP	On request	230/115 VAC	13.7 VDC	915 VDC	20/18 A	274 W	75 x 173 x 122 mm	***)
ADC57xy	$\underline{xy} = 83$	90264 VAC	27.4 VDC	2129 VDC	2.2 A	60 W	51 x 121 x 81 mm	
ADC51xy	$\underline{xy} = 83$	230/115 VAC	27.4 VDC	2129 VDC	5 A	137 W	66 x 148 x 113 mm	
ADC54xy	$\underline{xy} = 83$	230/115 VAC	27.4 VDC	2129 VDC	10 A	274 W	75 x 173 x 122 mm	**)
ADC54xyP	$\underline{xy} = 83$	230/115 VAC	27.4 VDC	2129 VDC	10 A	274 W	75 x 173 x 122 mm	
ADC59xy	On request	90264 VAC	41.4 VDC	3344 VDC	1.5 A	60 W	51 x 121 x 81 mm	***)
ADC58xy	$\underline{xy} = 83$	90264 VAC	54.8 VDC	4558 VDC	1.1 A	60 W	51 x 121 x 81 mm	
ADC52xy	On request	230/115 VAC	54.8 VDC	4558 VDC	2.5 A	137 W	66 x 148 x 113 mm	
ADC55xy	$\underline{xy} = 83$	230/115 VAC	54.8 VDC	4558 VDC	5 A	274 W	75 x 173 x 122 mm	**)
ADC55 <u>xy</u> P	<u>xy</u> = 93	230/115 VAC	54.8 VDC	4558 VDC	5 A	274 W	75 x 173 x 122 mm	
8750230A	750230A Finger protected power cord for ADC5000-series models							

Device and finger protected power cord must installed place where only skilled person access.

### \*) x selection code:

Mounting versions in Power supply models: 2=DIN-rail 3=Wall 8=DIN-rail 9=Wall Mounting versions in Rectifier models:

## Marking plate sticker

See type number and serial number details here

### y selection code:

Standard features: All models

8750230A

1 = Module fail alarm relay + Output over voltage protection (OVP),

3 = Output series diode + Module fail alarm relay + Output OVP

Optional features:

125/250W Power supply 0 = Alarm relay + Shut down, 2 = Output series diode + Alarm relay + Shut down, (No OVP)

125/250W Rectifier 4 = Output remote control for battery test + alarm relay + Output OVP,

Finger protected power cord for ADC5000-series models


 $5 = Output \ remote \ control \ for \ batter \underline{y} \ test + alarm \ rela \underline{y} + Output \ OVP + Output \ series \ diode$ 

### Letter P models include passive power factor correction coil

\*\*) Marked model does not comply with EN61000-3-2 harmonics standard.

These can be used in following applications: the unit is not directly connected to the public mains network, or if the unit is installed in a professional equipment with a total rated power greater than 1kW, or if the input current of the equipment is greater than 16A per phase

\*\*\*) Marked models are not UL508 listed, 12V/20A model max current with series diode 18A








### **SPECIFICATION**

		60	$\mathbf{w}^{-}$			125W			250W	
	12V	24V	36V	48V	12V	24V	48V	12V	24V	48V
INPUT				l	l	l				ı
Input voltage		AC / 8520 is not UL623		ved)	94132 V	AC or 1842	264 VAC sel	lectable b <u>y</u> s	witch	
Frequenc <u>y</u>	4565Hz									
Input current, 100% load, 230VAC	0.8A				1.4A			ADC5xxx 2.	5A, ADC5xxx	kP 1.9A
Input current, 100% load, 115VAC	1.4A				2.4A			ADC5xxx 4.	5A	
Efficiency, typical (230 VAC, 100% load)	>82%	>83%	>83%	>84%	>85%	>88%	>89%	>85%	>89%	>90%
Isolation	Input / gro	und 1500 V	AC RMS 50	Hz, 1min, I	nput / output	3000 VAC	RMS 50Hz,	1min.Outpu	t / ground 50	00 VDC
Inrush current (25C°), 230VAC	<25A <5m				<45A <5ms			<35A <5m		
Inrush current (25°C), 115VAC	<12A <101				<22A <10n			<17A <10r		
Input fuse	T3.15A, high breaking T4A, high breaking				T6.3A, High breaking					
Overvoltage transient protection	VDR 300V	AC 77J								
OUTPUT	1077	2477	2617	4077	1017	2477	4077	1017	0.477	4077
Output voltage, PSU models (50% load)	12V	24V	36V	48V	12V	24V	48V	12V	24V	48V
Output voltage, rectifiers (50% load)	13.7V 10,515V	27.4V	41.1V	54.8V	13.7V	27.4V	54.8V	13.7V	27.4V	54.8V
Output adjustment (typical)		2129V	3344V	4558V	915V	2129V	4558V	915V	2129V	4558V
Ripple voltage (20Hz300kHz, 25°C)	<15mV <sub>rms</sub>			T	<15mV <sub>rms</sub>	<15mV <sub>rms</sub>	<15mV <sub>rms</sub>	<15mV <sub>rms</sub>	<15mV <sub>rms</sub>	<15mV <sub>rms</sub>
Load regulation (without series diode)	<1.0 %	<0.5 %	<0.5 %	<0.5 %	<1.0 %	<0.5 %	<0.5 %	<1.0 %	<0.5 %	<0.5 %
Line regulation		UinminUin	ımax							
Temperature coefficient	< 0.02 % /	°C								
Current limit (refer curve page 5)	<8A	<4A	<3A	<2A	<11A	<6A	<3A	<22/20A	<11A	<6A
Short circuit current (refer curve page 5)	<14A	<9A	<8A	<6A	<16A	<10A	<6A	<27A	<14A	<9A
Hold-up time (230V, 100% load)	>50ms	>50ms	50ms	50ms	>20ms	>20ms	>20ms	>20ms	>20ms	>20ms
ALARMS AND INDICATIONS				_	•	=	•	-	-	-
Output OK	Green LEI	)								
Power Fail relay alarm	Relay contacts Normally Open and Closed, Activated at AC fail and module fail cases									
		act rating ma			/AC/0.5A azardous vo	ltage require	ed!			
Under voltage alarm threshold level		V 20V ±1V			8.3V ±0.5V	19V ±1V	39V ±2V	8.3V ±0.5V	19V ±1V	39V ±2V
Output overvoltage protection level	16V	30,5V	46V	61V	16V	31V	60V	16V	31V	60V
Series diode at output	Output can	be equipped	l with interr	nal series die	ode, diode in	125/250W	models, FET	circuit in 60	)W models	1
Optional Shutdown	Shutdown	b <u>y</u> external v	oltage 4	15VDC to F	C pin					
Optional battery test control						to allow batt	ery test by usin	ng external me	asurement cir	cuit
Temperature compensation (rectifiers)	By externa	1 NTC resist	or 2.2 kohm	n, included i	n rectifier m	odels delive	ry No ext	ernal voltage	allowed!	
MECHANICAL	_			<u> </u>			•			
Dimensions (w x h x d)	51 x 121 x 81 mm 66 x 148 x 113 mm  Can be installed both horizontally and vertically (3 different installation choices)				n choices)	75 x 173 x 122 mm				
Weight	360 g		orizoniun <u>,</u>	and vortical	840 g		· choices)	ADC5xxx 1.	3kg, ADC5xx	xP 1.5kg
Enclosure	Steel / aluminium enclosure IP20						,	8		
Connectors		2.5 mm <sup>2</sup> sc		ıle						
ENVIRONMENTAL	Kemovaok	2.5 mm sc	rew termine	113						
Storage temperature	-40°C+	85°C								
Operation temperature	-40°C+	70°C, full po	wer up to +	-55C (expec	t 250W/12V	DC, 24VDC	models), Se	ee derating c	urves	
Pollution degree	Maximum	-40°C+70°C, full power up to +55C (expect 250W/12VDC, 24VDC models), See derating curves Maximum pollution degree 2 allowed								
Cooling	Natural co	nvection								
Humidit <u>v</u>	85% RH 95% RH coated PCBs in R-versions									
Shock and vibration	Do not energize while condensation is present.  ETS 300 019-2-4, class 4M5,  Vibration, sin, IEC60068-2-6, 2g <sub>n</sub> 9-200m/s <sup>2</sup> , Vibration, broad-band random, IEC60068-2-64									
STANDARDS, APPROVALS	v ioration,	siii, iEC0000	50-2-0, 2g <sub>n</sub>	<i>z-2</i> 00III/S²,	v ibiadoli, bi	oau-panu ra	ndom, IECO	0000-2-04		
Safety standards	IEC 62368	-1:2018 Nat	ional Differ	ences: EU C	Group Differ	ences, CA, U	JS			
	IEC 62368-1:2018 National Differences: EU Group Differences, CA, US UL508 industrial control equipment (not all models, refer page 2)									
EMC emissions EN61000-6-3	EN 55022 class B conducted and radiated emissions EN61000-3-2 harmonics (not 250W models without P in type number)									
EMC Immunity		3-3 Flickerin	_	rge						
ENG 1000-6-2	EN 61000-4-2 Electrostatic Discharge EN 61000-4-3 Radiated Immunity EN 61000-4-4 Fast Transients									
1	EN 61000-4-5 Surge EN 61000-4-6 Conducted Immunity									
					1 (					
	TEN 61000-	4-x Power f	requency m	agnetic field	l immunity					
		4-11 Voltag								



### PIN CONFIGURATION 60W MODELS



### INPUT CONNECTOR

- 1: Protective Earth
- 2: N (+ if used at DC network)
- 3: L (- if used at DC network)


### OUTPUT CONNECTOR

- 1: Output -
- 2: Output +
- 3: Not in use (Y selection code 1 or 3) OR 4...15VDC control to allow Remote control input in shut down models (Y selection code 0 or 2)
- 4,5: Temperature compensation NTC sensor (No external voltage allowed!)
- 6: Alarm relay, normally closed (relay not energized)
- 7: Alarm relay, normally open (relay not energized)
- 8: Alarm relay, common

Galvanic reinforced isolation from the mains hazardous voltage required!

 $Use \ 60/75 \ or \ 75^{\circ}C \ copper \ (CU) \ wire \ only. \ The \ recommended \ terminal \ tightening \ torque \ is \ 0.5Nm. \ Relay \ contact \ rating: \ 24VDC/0.3A \ / \ 30VAC/0.5A \ (CO) \ (CO)$ 

### PIN CONFIGURATION 125W MODELS



### INPUT CONNECTOR

- 1: Protective Earth
- 2: N
- 3: L


### OUTPUT CONNECTOR

- 1: Output –
- 2: Output +
- 3,4: Temperature compensation NTC sensor (No external voltage allowed!)
- 5: Alarm relay, normally closed (relay not energized)
- 6: Alarm relay, normally open (relay not energized)
- 7: Alarm relay, common
- 8: Not in use (Y selection code 1 or 3) OR 4...15VDC control to allow Remote control input in shut down (Y=0 or 2) or battery test models (Y=4 or 5)

Galvanic reinforced isolation from the mains hazardous voltage required!

 $Use \ 60/75 \ or \ 75^{\circ}C \ copper \ (CU) \ wire \ only. \ The \ recommended \ terminal \ tightening \ torque \ is \ 0.5Nm. \ Relay \ contact \ rating: \ 24VDC/0.3A \ / \ 30VAC/0.5A$ 

### PIN CONFIGURATION 250W MODELS



### INPUT CONNECTOR

- 1. Protective Earth
- 2: N
- 3: L

### **OUTPUT CONNECTOR**


- $\begin{array}{lll} 1,2: & Output & Note: Rated current 12A \ / \ pin \\ 3,4,5: & Output + & Note: Rated current 12A \ / \ pin \end{array}$
- 6: Temperature compensation NTC sensor (No external voltage allowed !)
- 7: Alarm relay, normally closed (relay not energized)
- 8: Alarm relay, normally open (relay not energized)
- 9: Alarm relay, common
- 10: Temperature compensation NTC sensor (No external voltage allowed !)
- 11: Not in use (Y selection code 1 or 3) OR 4...15VDC control to allow

Remote control input, shut down (Y=0 or 2) or battery test (Y=4 or 5) models

Galvanic reinforced isolation from the mains hazardous voltage required! Use 60/75 or 75°C copper (CU) wire only. The recommended terminal tightening torque is 0.5Nm. Relay contact rating: 24VDC/0.3A / 30VAC/0.5A



### **DIMENSIONS**





	60W	125W	250W
W	51 mm	66 mm	75 mm
Н	121 mm	148 mm	173 mm
D	81 mm	113 mm	122 mm

### FREE INSTALLATION CHOICE

Due to movable DIN –rail connectors 5000series modules can be flexibly installed to the available space


### **CURRENT LIMITING CURVES**







Please note that curves present the current limiting principle only. Exact values and shape of curves varies between different models, refer specification.


### POWER DERATING CURVES



### TEMPERATURE COMPENSATION EFFECT TO FLOAT CHARGE VOLTAGE







Temperature compensation sensor 2.2k ohm NTC resistor is included in rectifier models (x = 7, 8 or 9) delivery



#### INTENDED USE

The power supply shall only be installed and put into operation by qualified and skilled personnel and place where only skilled person access. This power supply is designed for building purposes in an enclosure and is intended to be used in industrial and telecom applications. Units can be used as a power supply or for float charging batteries in standby battery back-up solutions. For safety reasons external max 40A fuse or circuit breaker must be installed between the rectifier and battery.

R-version units also fulfill demanding environmental requirements like shocks, vibration, humidity and wide ambient temperature range. 250W units without P in the end of type number do not comply with EN61000-3-2 harmonics standard. These units are intended to be used in non-public networks only.

#### SAFETY PRECAUTIONS

Do not use the unit without proper earth connection (Protective Earth). Turn power off from AC input wires before working with the power supply. Units are intended to be used as permanently connected equipment (excluding bench models with fixed power cord). Readily accessible disconnection device circuit breaker max 20A or fuse shall be incorporated in building installation wiring. If unit is used for charging batteries, external max 40A fuse or circuit breaker must be installed between the rectifier and battery.

#### WARNING:

Dangerous voltages, capable of causing death, are present in this equipment. Do not remove the cover. No operator serviceable parts inside. Refer servicing to qualified service personnel.

### 115/230V INPUT VOLTAGE SELECTION

#### 125/250W models:

The unit is factory set to operate with a 230V nominal input voltage. The nominal input voltage can be selected via the internal 115/230 voltage selector on the PCB. Access to the selector is through the ventilation holes of the unit cover. Always disconnect power before selecting.

#### 60W models

The unit is wide input type and will work without modification from 90VAC to 264VAC.

#### USING UNIT WITH DC INPUT

60W units can be operated also by DC input voltage. See voltage range from specification and connection from pin configuration. Note! DC input is not UL62368-1 approved.

### OUTPUT VOLTAGE ADJUSTMENT AND BATTERY CHARGING APPLICATIONS

The output voltage of the module can be adjusted with the multi-turn potentiometer located on the front panel. All models can be used either as a power supply or a standby battery charger by correct adjustment. Please note that the output of the unit **is not reverse voltage protected** and wrong battery polarity will break the unit. So pay attention to the correct polarity.

Note! For safety reasons external max 40A fuse or circuit breaker must be installed between the rectifier and battery.

125W and 250W models: Maximum output current is available within the full voltage adjustment range.

60W models: Maximum output power is available within the full voltage adjustment range

### ALARM RELAY

The potential free alarm output indicates if the output of the unit is healthy. Alarm relay contacts, both normally open and normally closed, are presented on the unit connector. If the output is healthy, the NO and COM pins are short circuited. If the unit fails the relay contacts will changeover and NC and COM pins will be short circuited. Word "normal" in relay pins means that mode when relay is not energized.

### SERIES / PARALLEL CONNECTION

Reserve 2cm space on both sides for proper cooling.

Parallel operation: Passive load sharing. Do not chain the outputs, rated current 12A / pin. Recommended cable size: 2.5mm², length > 0.5m for optimum load sharing. External series diodes are needed for parallel connection of 60W models (FET type built in "series diode circuit" does not work properly in parallel connection). 125/250W models can be connected in parallel with or without series diodes. Redundant n+1 system can be made only with series diodes.

Series operation: Up to 500V total voltage.

### TEMPERATURE COMPENSATION

Temperature compensated charging provides the optimum float charge voltage when batteries are being used. To utilize this feature it is necessary to install a NTC sensor across the temperature compensation pins on the output connector. It is also necessary to set the jumper on the front panel to ON position. The output voltage should be adjusted when the jumper is in the OFF position. This will simulate room temperature and ensure accuracy. The recommended sensor type is a 2.2k ohm NTC resistor, e.g. Epcos B57164-K222-K. The sensor should be installed local to the batteries. The sensor is galvanically connected to the + output. Temperature compensation sensor is included in rectifier models (x = 7, 8 or 9) delivery

### LED

A green LED indicates that the output of the module is healthy.

### OUTPUT OVERCURRENT PROTECTION

Automatic, self-resetting electronic current limiting is included and the output is short circuit proof.

### OUTPUT OVER VOLTAGE PROTECTION (OPTION)

Output of the unit will shut down if the output voltage rises above protection level. (16Volts/12V models, 31Volts/24V models and 58 Volts/48V models). Protection must be manually resetted by disconnecting the AC mains voltage.

### OUTPUT VOLTAGE REMOTE SHUT DOWN AND BATTERY TEST OPTIONAL MODELS

Output of the unit will shut down, when a +4...15VDC signal is applied to the remote control input (RC) with reference to negative output. In battery test models output voltage drops 15-25% when a +4...15VDC signal is applied to the RC pins as above. The output voltage will return to the original level, when +4...15VDC signal is removed from RC pins.

### INTERNAL OUTPUT SERIES DIODE OPTION (125/250W series diode, 60W FET circuit)

The internal diode is placed in series with the positive output. The benefits of having the diode fitted are:

- Improved redundancy if the modules are connected in parallel (not for 60W models, external series diode needed)
- Power OK signal and LED work independently regardless battery or parallel connections
- The parallel connected modules can be Hot Plug replaced without the system output power interruption (60W models need external series diode)
- The reverse current bleed is low if a battery is connected to the output of the rectifier

The disadvantages of having the diode fitted are lower efficiency, deration to the output voltage regulation and load sharing.

Note: The output series diode does not protect against reverse polarity connection of the battery.